




CODE	DESCRIPTION	CODE	DESCRIPTION	CODE	DESCRIPTION
AC001-011	Pressure Switch 3/8" (start valve open)	AC009-103	No-vibration rubber	AC024-050	Wheel
AC001-011-001	Pressure Switch EXTREME TN 22	AC009-402	Rubber mats	AC030-220-3001	Tank EXTREME TN 22L. "RED"
AC002-051	Pin plug SHUKO 1,5 m	AC011-013	Blue Rilsan tube for EXTREME TN 22L.	AC034-100-9005	Carry tools
AC003-022	Safety valve 10 BAR PED	AC012-104	Rilsan tube for EXTREME TN 22L.	AC034-150-9005	Handle
AC004-002	Pressure regulator MIGNON Pos.2	AC014-002	Closure plug	VB006-040	Screw
AC004-002-002	Pressure regulator for EXTREME TN 22	AC014-004	Closure plug	VB006-085	Screw
AC005-001	Manometer 40 mm 1/4" Bar/Psi	AC016-002	Reduction	VB012-005	Screw
AC005-011	Manometer 50 mm 1/4" Bar/Psi	AC017-051	Pipe filling "L"	VD006-005	Nut
AC006-001	Universal Coupler 1/4" Male	AC017-102	Pipe filling "L"	VD008-005	Nut
AC007-005	Condensate drain valve	AC017-410	Pipe filling "L"	VD012-005	Nut
AC008-002	Not return valve 3/8" complete for tube Rilsan	AC019-053	Pipe filling "T"	VR012-010	Washer
AC008-004	Ogive for tube blue Rilsan	AC021-013	Threaded extension		
AC008-005	Nut for tube blue Rilsan	AC021-016	Pin wheel		

CODE	TUBE FOR UNIT PUMP	CODE	TUBE FOR UNIT PUMP	CODE	TUBE FOR UNIT PUMP
AC026-059	Flexible tube	AC026-061	Flexible tube		